

ELECTRICAL GAUGES W/WARNING

60mm JDM SERIES WHITE / AMBER LED DISPLAY

Tachometer

OPENING CEREMONY

1

RED - BATTERY (+)
BLACK - ENGINE GROUND.
WHITE - IGNITION SWITCH 12V+
ORANGE - DIMMER / +12V TO DIMMER
CONNECT TO HEADLIGHT TO ACTVAE.

BACK VIEW

2

SET Button

3

WARNING LIGHT HAVE TO BUY EXTRALY.

4

5

CYLINDER SELECTION SWITCH

1. Selecting Number of Cylinders:
Setting the tacho for 4, 6 or 8 (4, 6 or 3) cylinder operation is achieved simply by sliding the switch, located on back of the tachometer body, to coincide with the appropriate number of cylinders of the engine.

2. Switch position:
0=10 cylinders, 1=1 cylinders, 2 = 2 cylinders
3=3 cylinders, 4=4 cylinders, 5=cylinders,.....

3. When setting the number of cylinders for a rotary engine, set the cylinders number selection to 4 cylinders for 2 rotors, and to 6 cylinders for 3 rotors.

4. The red or black wire **MUST** be removed before adjustment to the cylinder setting is made from the cylinder selector switch.

6

BACK VIEW

7

8

Complete Set

Voltmeter

OPENING CEREMONY

1

RED - BATTERY (+)
BLACK - ENGINE GROUND.
WHITE - IGNITION SWITCH 12V+
ORANGE - DIMMER / +12V TO DIMMER
CONNECT TO HEADLIGHT TO ACTVAE.

BACK VIEW

2

SET Button

3

WARNING LIGHT HAVE TO BUY EXTRALY.

4

5

BACK VIEW

RED - BATTERY (+)
BLACK - ENGINE GROUND.
WHITE - IGNITION SWITCH 12V+
ORANGE - DIMMER / +12V TO DIMMER
CONNECT TO HEADLIGHT TO ACTVAE.

6

7

Complete Set

8

Einstellungen für die JDM Serie Prosport 60mm

Einstellungen für die Alarmgrenze:

Nach der Start Sequenz den vorderen Knopf an der Anzeige drücken und halten für etwa 5 Sekunden. Dann blinkt die Anzeigenadel und der äußere Anzeigering im Instrument. Jetzt den Knopf loslassen. Durch erneutes drücken & halten kann die Anzeigenadel (Alarmwert) verändert werden. Wenn die gewünschte Position erreicht ist, den Knopf loslassen und der Wert wird autom. nach ein paar Sekunden gespeichert.

Einstellungen für den Alarmton:

Bei ausgeschaltetem Instrument den vorderen Knopf am Instrument drücken, halten und dann zusammen die Zündung einschalten. Nach der Startsequenz kann der Knopf losgelassen werden. Der Alarmton ist ausgeschaltet. Das gleiche um den Alarmton wieder einzuschalten.

Einstellungen für die Hintergrundbeleuchtung:

Es stehen zwei Hintergrundfarben zur Verfügung. Weiss & Orange. Durch Knopfdruck am vorderen Einstellknopf kann die Farbe in der Startsequenz verändert werden.