

ELECTRICAL GAUGES W/WARNING

SMOKE LENS & ANGEL RING GAUGE SUPER WHITE LED DISPLAY

Air fuel / ratio

OPENING CEREMONY

1 BACK VIEW POWER WIRE HARNESS DAISY CHAIN POWER WIRE HARNESS (EITHER SIDE IS OK) RED - BATTERY (+). BLACK - ENGINE GROUND. WHITE - IGNITION SWITCH 12V+ ORANGE - DIMMER / +12V TO DIMMER CONNECT TO HEADLIGHT TO ACTIVATE.	2 VISOR BUFFER METER METER CUP & HOLDER	3	4 52MM
5 + -	6 **The warning is AFR lower Lean. CONNECTOR FOR SENSOR WIRE SENSOR WIRE WHITE RED CONNECTOR O2 SENSOR SIGNAL WIRE ECU (ENGINE COMPUTER UNIT) BACK VIEW	7 + -	

Boost / Vacuum Gauge

OPENING CEREMONY

1 BACK VIEW POWER WIRE HARNESS DAISY CHAIN POWER WIRE HARNESS (EITHER SIDE IS OK) RED - BATTERY (+). BLACK - ENGINE GROUND. WHITE - IGNITION SWITCH 12V+ ORANGE - DIMMER / +12V TO DIMMER CONNECT TO HEADLIGHT TO ACTIVATE.	2 VISOR BUFFER METER METER CUP & HOLDER	3	4 52MM
5 BOOST INSTALLATION Boost / Vacuum Sensor Surge Tank Pressure Regulator Boost Sensor Red White Black T-Fitting Air Filter Hose	6 **The warning is boost exceed 1.5Bar(21Psi). **The warning is vacuum exceed 0 Bar(0 In.Hg). CONNECTOR FOR SENSOR WIRE SENSOR WIRE WHITE CONNECTOR BLACK WHITE RED VACUUM / BOOST SENSOR	7 + -	