

INSTALLATION INSTRUCTIONS ELECTRICAL GAUGES


STEPMOTOR MOVEMENT JAPAN

SMOKE LENS SERIES WHITE & AMBER LED DISPLAY


OPENING CEREMONY

Boost Gauge

1




2




3

BOOST INSTALLATION




4




Press Gauge For Oil Press


5



6




7




Press Gauge For Fuel Press


8



9



10



1. Connect power wire (RED) to +12V battery wire.
2. Connect power wire (BLACK) to ground, negative (-) battery terminal or a good chassis ground.
3. ORANGE - Note
4. WHITE - Note



NOTE: GAUGE REQUIRE FUNCTION

REQUIRE FUNCTION		DETAILATION
DAYTIME	ROCKET TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE → CONNECT TO ACC
		ORANGE WIRE → NO CONNECT
AMBER RED	AMBER RED	WHITE WIRE → NO CONNECT
SCALE	SCALE	ORANGE WIRE → CONNECT TO ACC
WHITE SCALE	AMBER RED	WHITE WIRE → CONNECT TO ACC
	SCALE	ORANGE WIRE → CONNECT TO PARKING LAMP
AMBER RED	WHITE SCALE	ORANGE WIRE → CONNECT TO ACC
SCALE	SCALE	WHITE WIRE → CONNECT TO PARKING LAMP