

## ELECTRICAL GAUGES REMOTE CONTROLLER SERIES

SMOKE LENS & ANGEL RING GAUGE WHITE / BLUE / AMBER LED DISPLAY

### Fuel Press Gauge

### OPENING CEREMONY

<p><b>1</b></p> <p><b>BACK VIEW</b></p> <p>RED - BATTERY (+). BLACK - ENGINE GROUND. WHITE - IGNITION SWITCH 12V+ ORANGE - DIMMER / +12V TO DIMMER CONNECT TO HEADLIGHT TO ACTIVAE.</p>	<p><b>2</b></p>	<p><b>3</b></p> <p>DOUBLE-SIDED TYPE</p> <p>WARNING LIGHT HAVE TO BUY EXTRALY.</p>	<p><b>4</b></p> <p>PRESS SENSOR</p>
<p><b>5</b></p>	<p><b>6</b></p> <p>FUEL PRESS SENSOR</p>	<p><b>7</b></p> <p>Warning LED Red</p>	<p><b>8</b></p> <p>Complete Set</p>

### Exhaust Gas Temperature Gauge

### OPENING CEREMONY

<p><b>1</b></p> <p><b>BACK VIEW</b></p> <p>RED - BATTERY (+). BLACK - ENGINE GROUND. WHITE - IGNITION SWITCH 12V+ ORANGE - DIMMER / +12V TO DIMMER CONNECT TO HEADLIGHT TO ACTIVAE.</p>	<p><b>2</b></p>	<p><b>3</b></p> <p>DOUBLE-SIDED TYPE</p> <p>WARNING LIGHT HAVE TO BUY EXTRALY.</p>	<p><b>4</b></p> <p>EXHAUST GAS TEMP SENSOR</p> <p>PINK - CONNECT TO SENSOR WIRE WHITE WIRE BLUE - CONNECT TO SENSOR WIRE BLACK WIRE</p>
<p><b>5</b></p>	<p><b>6</b></p> <p>EXHAUST GAS TEMP SENSOR</p>	<p><b>7</b></p> <p>Warning LED Red</p>	<p><b>8</b></p> <p>Complete Set</p>

**Note: The remote-controller have to buy extraly.**