


## ELECTRICAL GAUGES

SMOKE LENS SERIES AMBER RED & SUPER WHITE LED DISPLAY







(270° SCALE)

### Fuel Press Gauge

#### OPENING CEREMONY




- RED - TO IGNITION SWITCH 12V(+)
- BLACK - BATTERY(-)
- GREEN - FUEL PRESS SENSOR
- WHITE - NOTE
- ORANGE - NOTE




**NOTE: GAUGE REQUIRE FUNCTION**

REQUIRE FUNCTION		INSTALLATION
DAY TIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE→connect to ACC. AMBER WIRE→NO connect
AMBER SCALE	AMBER SCALE	WHITE WIRE→NO connect AMBER WIRE→connect to ACC.
WHITE SCALE	AMBER SCALE	WHITE WIRE→ connect to ACC AMBER WIRE→connect to PARKING LAMP
AMBER SCALE	WHITE SCALE	WHITE WIRE→connect to PARKING LAMP AMBER WIRE→connecto to ACC.








### Boost / Vacuum Gauge


#### OPENING CEREMONY



- RED - TO IGNITION SWITCH 12V(+)
- BLACK - BATTERY(-)
- GREEN - BOOST SENSOR
- WHITE - NOTE
- ORANGE - NOTE



- RED - TO IGNITION SWITCH 12V(+)
- BLACK - BATTERY(-)
- WHITE - GREEN WIRE FROM GAUGE



**NOTE: GAUGE REQUIRE FUNCTION**

REQUIRE FUNCTION		INSTALLATION
DAY TIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE→connect to ACC. AMBER WIRE→NO connect
AMBER SCALE	AMBER SCALE	WHITE WIRE→NO connect AMBER WIRE→connect to ACC.
WHITE SCALE	AMBER SCALE	WHITE WIRE→ connect to ACC AMBER WIRE→connect to PARKING LAMP
AMBER SCALE	WHITE SCALE	WHITE WIRE→connect to PARKING LAMP AMBER WIRE→connecto to ACC.

