

INSTALLATION INSTRUCTIONS ELECTRICAL GAUGES

52mm DIGITAL LCD SERIES BLUE / RED DISPLAY

QUAD AIR PRESSURE GAUGE

1

Red
White
Black
Orange

POWER WIRE HARNESS

Red Wire- 12v Accessory Power
White Wire- 12v Accessory Power
Black Wire- Ground
Orange Wire- 12v Headlight Switched Power
(This is a power source that only gets power when headlights are on)

2

(RF) SENSOR WIRE HARNESS
(LF) SENSOR WIRE HARNESS
SENSOR WIRE HARNESS (RR)
SENSOR WIRE HARNESS (LR)
POWER WIRE HARNESS

3

4

5

Lighting Options

Day Time	Night Time	Installation
Blue	Blue	White-- Connect to acc. Power Orange-- Do not connect
Red	Red	White-- Do not connect Orange-- Connect to acc. Power
Blue	Red	White-- Connect to acc. Power Orange-- Connect to Headlight Switched Power
Red	Blue	White-- Connect to Headlight Switched Power Orange-- Connect to acc. Power

6

1/8 NPT THREAD
PRESS SENSOR

7

Cockpit System

MOUNTING CUP
HAVE TO BUY EXTRALY

1

2

3

Metal 2 m/m
Plastic 1.3 m/m

4

5

6

7

Detergent

8

9

10

11

12

13

14