

ELECTRICAL GAUGES

SMOKE LENS SERIES AMBER RED & SUPER WHITE LED DISPLAY

(270° SCALE)

Fuel Press Gauge

OPENING CEREMONY

1

RED - TO IGNITION SWITCH 12V(+)
 BLACK - BATTERY(-)
 GREEN - FUEL PRESS SENSOR
 WHITE - NOTE
 ORANGE - NOTE

2

3

4

CONNECT TO GAUGE GREEN WIRE

PRESSURE SENDER

BATTERY (-)

5

Fuel pressure regulator

Wind teflon tape

To sensor wire

sensor

Be sure not to twist

Hose union (commercially available)

Three-way joint (commercially available)

Fix tightly with clamps (commercially available)

Fuel return pipe (low pressure)

*Cut the fuel feed pipe and install hose unions.

Fuel feed pipe (high pressure)

6

GREEN

BLACK - GROUND

WHITE - (NOTE)

ORANGE - (NOTE)

RED

7

NOTE: GAUGE REQUIRE FUNCTION

REQUIRE FUNCTION		INSTALLATION
DAY TIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE→connect to ACC. AMBER WIRE→NO connect
AMBER SCALE	AMBER SCALE	WHITE WIRE→NO connect AMBER WIRE→connect to ACC.
WHITE SCALE	AMBER SCALE	WHITE WIRE→ connect to ACC AMBER WIRE→connect to PARKING LAMP
AMBER SCALE	WHITE SCALE	WHITE WIRE→connect to PARKING LAMP AMBER WIRE→connect to ACC.

8

Boost / Vacuum Gauge

OPENING CEREMONY

1

RED - TO IGNITION SWITCH 12V(+)
 BLACK - BATTERY(-)
 GREEN - BOOST SENSOR
 WHITE - NOTE
 ORANGE - NOTE

2

3

4

52mm

52mm

5

BOOST INSTALLATION

Boost / Vacuum Sensor

Surge Tank

Pressure Regulator

Boost Sensor

Red White

Black

Hose

Air Filter

T-Fitting

RED - TO IGNITION SWITCH 12V(+)
 BLACK - BATTERY(-)
 WHITE - GREEN WIRE FROM GAUGE

6

BOOST SENSOR

GREEN

BLACK - GROUND

WHITE - (NOTE)

ORANGE - (NOTE)

RED

7

NOTE: GAUGE REQUIRE FUNCTION

REQUIRE FUNCTION		INSTALLATION
DAY TIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE→connect to ACC. AMBER WIRE→NO connect
AMBER SCALE	AMBER SCALE	WHITE WIRE→NO connect AMBER WIRE→connect to ACC.
WHITE SCALE	AMBER SCALE	WHITE WIRE→ connect to ACC AMBER WIRE→connect to PARKING LAMP
AMBER SCALE	WHITE SCALE	WHITE WIRE→connect to PARKING LAMP AMBER WIRE→connect to ACC.

8